Kamal & Co

L.E.D Tennis Score Board - RF

We make LED display boards with LED's of various sizes, brightness and colours. We make boards as per your specification and layout.
Our boards can accept inputs from various sources including Your **PC**, **RS232**, **RS485, RF, PLC**, **Relay contacts**, **DC Input**, **Hand Held Remote Controls (IR)**, **Keypad, SMS** etc.

Just mail your requirement right away - We will revert with complete specs, visuals and estimate within hours by email
We can follow this up with a site visit and a demonstration of the product (wherever possible)

We offer Wireless - RF based solutions for your various display board requirements. We can incorporate such RF based wireless interface into our LED Display systems and boards. The Wireless solutions are best suited for transmission of data within the specified area without any messy connecting cables or connecters. The Transmission and the Receiving units can be shifted from one place to another (within the operational area) without any change in the package settings.

We offer customized solutions to clients and offer tailor made products with speed, economy and reliable performance.

In this PDF we have highlighted the LED Tennis Score Board - RF.

The requirement of the client was as follows:

1. Tennis Score LED display board
2. 2 Wireless RF Tennis Score Boards
3. 1 Wireless RF Controller for sending scores to the LED board

Kamal & Co

L.E.D Tennis Score Board - RF

Wireless (RF) Tennis Score Boards
Qty 2 units

Height of LED's 12" (300mm) Day light Viewing Super Bright Red

Brief Specs:

❖ 12" high digits (300mm approx) Red - Outdoor viewing - good viewing very high brightness.

❖ UV resistant Red Oval LED's for good viewing angle of 110/60 degrees

❖ Edit / Entering of data via RF keypad

❖ GAME Column = Will toggle between 10 -30 - 40 - A – Blank

❖ SETS - 1 - 2 - 3 Column = Will toggle between 0 to 9 for both rows

❖ Single keypad to control both the boards

❖ The two boards will be inside the stadium and 100 meters apart.

❖ Memory for last keyed in data

❖ Board works off 230V AC - 50 Hz - Rugged MeanWell SMPS is used

❖ The board has a weather resistant enclosure with a hood on top.

Kamal & Co

L.E.D Tennis Score Board - RF

RF Keypad
Qty 1 unit

Brief Specs:

a. Good sheetmetal Powder coated console
b. RF console
c. LCD indicator for local viewing of scores on board
d. Clearly marked buttons to indicate the various menu
e. Computer etched markings for long life viewing of Menu
f. Edit / Entering of data via RF keypad
g. Single keypad to control both the boards
h. Memory for last keyed in data
i. Board works off 230V AC - 50 Hz - Rugged MeanWell SMPS is used

Kamal & Co

L.E.D Tennis Score Board - RF

OPERATION MANUAL OPERATION FOR TENNIS BOARD

1. **SELECT SERVICE KEY:**
   a. Press SERVICE key in Home or Guest – and the respective block of LED will light up ON the board.
   b. Press again SERVICE key in Home or Guest – and the respective block of LED will OFF condition.

2. **SELECT GAME SCORES:**
   a. First the board shows " - -" in the Game Windows and other window gets blank.
   b. Then if you Press the POINT button in Home or Guest once then the points toggle between 00, 15, 30, 40, GA.
   c. OR
   d. At Press SCORE* button in Home or Guest and press the required score in the Keypad and press ENTER*
   e. Press SCORE* button in Home or Guest and press CLEAR button in the Keypad to clear the game score.
   f. On reaching GA the board will not change any other set score.

3. **SELECT THE RESET GAME SCORES:**
   a. Press RESET GAME SCORE – both Game score windows go back to "- -".

4. **SELECT THE CURRENT SET SCORES:**
   a. Choose the Set by pressing "SET KEY" the desired number – 1,2 or 3 - in the keypad and press ENTER. Current set - will be indicated on the LCD DISPLAY should be blinking.

5. **CHANGE THE CURRENT SET SCORES:**
   a. PRESS "GAME+1" key to increment the set score on either Home or Guest.
   b. Press GAME* button in Home or Guest and press the required score in the Keypad and press ENTER*.
   c. Press GAME* button in Home or Guest and press CLEAR button in the Keypad to clear the current set score.

6. **CHANGE THE DEUCE BUTTON:**
   a. Press DEUCE button when both players are at dU will appear.
   b. CHANGE THE ADVANT BUTTON:
   c. Press ADVANT button when both players are at 40 and Ad will appear.

7. **CHANGE THE TIE BREAK BUTTON:**
   a. Press RESET GAME SCORE key and then Press TIE BREAK key.
   b. Press POINT button, for each press the game score increment once.
   c. Press the RESET GAME SCORE key to exit from tiebreaker mode to normal score operation.

8. **SELECT THE TOTAL RESET:**
   a. Press RESET GAME SCORE and 1,2,3 and SET button.(RESET GAME SCORE)+(1,2,3)+(SET). Note: If you Press either game* or score* then you have press Enter key otherwise no key work.